

CAM SWITCHES 20A , 25A



ON-OFF SWITCHES WITH 60° SWITCHING 20A , 25A

Code No.	Function	Escutch Plate	Stages	Connection diagram
C076	1 pole		1	
C077	2 pole		1	
C078	3 pole	2		
C079	4 pole	2		
C080	5 pole	3		
C081	6 pole	3		
C082	7 pole	4		
C083	8 pole	4		
C084	9 pole	5		
C085	10 pole	5		
C086	11 pole	6		



MULTI-STEP SWITCHES WITH "OFF" 20A , 25A

C087	1 pole 2 step		1		
C088	2 pole 2 step		2		
C089	3 pole 2 step		3		
C090	4 pole 2 step		4		
C091	5 pole 2 step		5		
C092	6 pole 2 step		6		
C093	1 pole 3 step		2		
C094	2 pole 3 step		3		
C095	3 pole 3 step		5		
C096	4 pole 3 step		6		
C097	5 pole 3 step		8		
C098	1 pole 4 step		2		
C099	2 pole 4 step		4		
C100	3 pole 4 step		6		
C101	4 pole 4 step		8		
C102	1 pole 5 step		3		
C103	2 pole 5 step		5		
C104	3 pole 5 step		8		
C105	1 pole 6 step		4		
C106	2 pole 6 step		7		
C107	3 pole 6 step		11		
C108	1 pole 7 step		4		
C109	2 pole 7 step		8		
C110	1 pole 8 step		5		
C111	1 pole 9 step		5		
C112	1 pole 10 step		6		
C113	1 pole 11 step		6		