

CAM SWITCHES 32A



ON-OFF switches 90°, 60° switching 32A

Code No	Function	Stage	Escutch Plate	Connecting Diagram	
A301	1 Pole	1		Stage 1 Stage 2 Stage 3 Stage 4 	
A301A	2 Pole	1			
A302	3 Pole	2			
A302A	4 Pole	2			
A303	5 Pole	3			
A303A	6 Pole	3			
A304	7 Pole	4			
A304A	8 Pole	4			

Change over switches without OFF 90°, 60° switching 32A

A307	1 Pole	1			
A308	2 Pole	2			
A309	3 Pole	3			
A310	4 Pole	4			

Change over switches without OFF with electrically isolated contacts 32A

A313	1 Pole	1			
A314	2 Pole	2			
A315	3 Pole	3			
A316	4 Pole	4			

Change over switches with center OFF 90°, 60° switching 32A

A317	1 Pole	1		A317~A320 	
A318	2 Pole	2			
A319	3 Pole	3			
A320	4 Pole	4			
A321	1 Pole	1		A321~A324 	
A322	2 Pole	2			
A323	3 Pole	3			
A324	4 Pole	4			

ON - OFF Power switches 90° 32A

PS31	1 Pole	1		Stage 1 Stage 2 	
PS32	2 Pole	1			
PS33	3 Pole	2			
PS34	4 Pole	2			