

CAM SWITCHES

Voltmeter switches with Off

| Code No. | Function | Stage | Connecting diagram | In / Out Put | |
|-------------------|----------------|-------|--------------------|--|--|
| VS 33 | 3 Phase 3 wire | 2 | | <input type="checkbox"/> 4 <input type="checkbox"/> V1 <input type="checkbox"/> R <input type="checkbox"/> V2 <input type="checkbox"/> S <input type="checkbox"/> 5 <input type="checkbox"/> T <input type="checkbox"/> 7 | |
| Escutch Plate | | | | <input type="checkbox"/> V2 <input type="checkbox"/> B <input type="checkbox"/> V1 <input type="checkbox"/> Y <input type="checkbox"/> N <input type="checkbox"/> R | |
| VS 34 | 3 Phase 4 wire | 3 | | <input type="checkbox"/> V2 <input type="checkbox"/> B <input type="checkbox"/> V1 <input type="checkbox"/> Y <input type="checkbox"/> N <input type="checkbox"/> R | |
| Escutch Plate | | | | <input type="checkbox"/> V2 <input type="checkbox"/> B <input type="checkbox"/> V1 <input type="checkbox"/> Y <input type="checkbox"/> N <input type="checkbox"/> R | |

Ammeter Switches

| Code No. | Function | Stage | Connecting diagram | In / Out Put | |
|-------------------|---|-------|---|--|--|
| AS 33 | 3 Phase 3 wire 2 current transformer | 2 | | <input type="checkbox"/> 4 <input type="checkbox"/> R <input type="checkbox"/> A1 <input type="checkbox"/> T <input type="checkbox"/> 8 <input type="checkbox"/> 5 <input type="checkbox"/> A2 <input type="checkbox"/> 7 | |
| AS34 | 3 Phase 4 wire 3 current transformer | 3 | | | |
| Escutch Plate | | | <input type="checkbox"/> A2 <input type="checkbox"/> B <input type="checkbox"/> <input type="checkbox"/> R <input type="checkbox"/> <input type="checkbox"/> Y <input type="checkbox"/> A1 <input type="checkbox"/> N | | |
| Escutch Plate | | | <input type="checkbox"/> A2 <input type="checkbox"/> B <input type="checkbox"/> <input type="checkbox"/> R <input type="checkbox"/> <input type="checkbox"/> Y <input type="checkbox"/> A1 <input type="checkbox"/> N | | |